



Joy in Technology

XOOPAR BOY MINI

Art Toy Wireless Speaker With Selfie Remote
Model No: XBOY81001

SPECIFICATIONS

Bluetooth Version: 4.2+EDR
 Transmission Distance: Up to 10M
 Output Power: 3W RMS
 Frequency Response: 100Hz-15KHz
 SNR: >80dB
 Battery Type: Li-Polymer 300mAh
 Rechargeable
 Battery Life: 3hours play time
 Input Power/Current: DC 5V/300mAh
 Interface: Micro USB(Recharge)
 Features: Stereo Pairing
 Selfie Shutter Remote



USER MANUAL

Manuel D'Utilisation

Specification & appearance subject to change without notice. All trademarks and registered trademarks are the property of their respective owners © 2019 Xoopar Ltd.



Made In China
www.xoopar.com
www.xoopar.com/xooparus
www.xoopar.fr



ADVICE TO CONSUMER

- 1) Hand it to electronic waste disposal to protect environment.
- 2) Slight heat increase while charging is normal.
- 3) Ventilation can help to extend battery life.
- 4) Do not put into direct sun or rain.

VIDEO MANUAL INCLUDED

We've added video guide to improve user experience. Please scan or enter the given links at the back of this page to access the video, enjoy!

VIDEO LINKS



www.youtube.com/
user/XooparHongKong



OR



i.youku.com/xoopar
(For China)



OVERVIEW

Computer Or AC

① Recharged by Micro USB cable
 ② On&Off / Selfie / Pairing
 Long Press 2 Press 3 Press

SINGLE SPEAKER MANUAL

1

3 sec. ON/OFF

It will say " Hello, I am on! "

ON/OFF

2

Name: XooparBoy Mini

CONNECTION

3

Press Twice

SELFIE

3

MUSIC

STEREO (2 SPEAKERS) PAIRING MANUAL

1

3 sec. ON/OFF

ON/OFF

2

Press 3 Times on Any ONE

PAIRING

3

Name: XooparBoy Mini

CONNECTION